



Imaging Supplies

| MARCA | MODELLO | LARGHEZZA mm | LUNGHEZZA mm | CODICE DAYTEK |
|----------|---------------------------------|--------------|--------------|---------------|
| ALCATEL | 3724 | 212 | 80 | 7104012 |
| ALCATEL | 3727 | 212 | 80 | 7104012 |
| ALCATEL | 3727 SF | 212 | 80 | 7104012 |
| ALCATEL | 3728 | 212 | 80 | 7104012 |
| ALFRED | 1400 | 220 | 100 | 7104003 |
| AMSTRAD | PPR 1000 | 212 | 80 | 7104012 |
| AMSTRAD | PPF | 220 | 100 | 7104003 |
| AMSTRAD | PPR 600 | 220 | 100 | 7104003 |
| BELGACOM | BELGAFAX 150 T | 212 | 80 | 7104012 |
| BETACOM | 700/800 | 220 | 100 | 7104003 |
| BETACOM | PPF 700 | 220 | 100 | 7104003 |
| BETACOM | PPF 800 | 220 | 100 | 7104003 |
| BETACOM | PPR 700 | 220 | 100 | 7104003 |
| BETACOM | PPR 800 | 220 | 100 | 7104003 |
| BRONDI | PARTNER 46 | 212 | 80 | 7104012 |
| BRONDI | START 45 | 212 | 80 | 7104012 |
| BRONDI | FAXON | 220 | 70 | 7104015 |
| BRONDI | FAXO' A4 | 220 | 70 | 7104015 |
| BROTHER | FAX - 1150 | 216 | 230 | 7104006 |
| BROTHER | FAX - 1200P | 216 | 230 | 7104006 |
| BROTHER | FAX - 1700P | 216 | 230 | 7104006 |
| BROTHER | INTELLIFAX 1250 | 216 | 230 | 7104006 |
| BROTHER | INTELLIFAX 1350 M | 216 | 230 | 7104006 |
| BROTHER | INTELLIFAX 1450 MC | 216 | 230 | 7104006 |
| BROTHER | INTELLIFAX 1550 MC | 216 | 230 | 7104006 |
| BROTHER | MFC 1650 | 216 | 230 | 7104006 |
| BROTHER | MFC 1750 | 216 | 230 | 7104006 |
| BROTHER | MFC 1850 | 216 | 230 | 7104006 |
| BROTHER | MFC 1950 MC | 216 | 230 | 7104006 |
| BROTHER | MFC 1950 MCplus | 216 | 230 | 7104006 |
| BROTHER | PC 101/102/103 | 216 | 230 | 7104006 |
| BROTHER | FAX - 1000P | 216 | 130 | 7104005 |
| BROTHER | FAX - 1550M | 216 | 130 | 7104005 |
| BROTHER | INTELLIFAX 1500 M / 1450 M | 216 | 130 | 7104005 |
| BROTHER | INTELLIFAX 900 / 1350 M | 216 | 130 | 7104005 |
| BROTHER | INTELLIFAX 950 M | 216 | 130 | 7104005 |
| BROTHER | INTELLIFAX 980 M | 216 | 130 | 7104005 |
| BROTHER | INTELLIFAX 1500 | 216 | 130 | 7104005 |
| BROTHER | PC 91 / PC 95 | 216 | 130 | 7104005 |
| BROTHER | FAX - 1010 | 216 | 135 | 7104008 |
| BROTHER | FAX - 1020 | 216 | 135 | 7104008 |
| BROTHER | FAX - 1020 plus | 216 | 135 | 7104008 |
| BROTHER | FAX - 1030 | 216 | 135 | 7104008 |
| BROTHER | FAX - 1170 | 216 | 135 | 7104008 |
| BROTHER | FAX - 1270 | 216 | 135 | 7104008 |
| BROTHER | FAX - 1350M | 216 | 135 | 7104008 |
| BROTHER | FAX - 1450M / 1570 MC | 216 | 135 | 7104008 |
| BROTHER | FAX - 1770 MFC / 1970 MFC | 216 | 135 | 7104008 |
| BROTHER | FAX - 750 SERIES | 216 | 80 | 7104008 |
| BROTHER | FAX 770 | 216 | 80 | 7104008 |
| BROTHER | FAX 870 MC | 216 | 80 | 7104008 |
| BROTHER | FAX 910 / 917 / 920 / 921 / 930 | 216 | 80 | 7104008 |

| | | | | |
|-----------|-----------------------------------|-----|-----|---------|
| BROTHER | FAX 931 / 940 / 750 / 760 / 870MC | 216 | 80 | 7104008 |
| BROTHER | MFC 870 MC | 216 | 80 | 7104008 |
| BROTHER | MFC 925 | 216 | 80 | 7104008 |
| BROTHER | MFC 970MC | 216 | 80 | 7104008 |
| BROTHER | FAX T 72 / T 74 / T 76 / T 78 | 216 | 47 | 7104004 |
| BROTHER | FAX T 82 / T 84 / T 86 / T 92 | 216 | 47 | 7104004 |
| BROTHER | FAX T 96 / T 98 / T 104 / T 106 | 216 | 47 | 7104004 |
| EGT | 4210 | 212 | 80 | 7104012 |
| EGT | 4710 Galeo | 212 | 80 | 7104012 |
| EGT | GALEO 4000 | 212 | 80 | 7104012 |
| EGT | GALEO 4600 | 212 | 80 | 7104012 |
| EGT | GALEO 4700 | 212 | 80 | 7104012 |
| HITACHI | HIFAX CFX-1-2 | 220 | 50 | 7104031 |
| INSIP | MAGICO | 212 | 80 | 7104012 |
| ITALTEL | CX 301 | 212 | 80 | 7104012 |
| ITALTEL | CX 401 | 212 | 80 | 7104012 |
| ITALTEL | CX 450 | 212 | 80 | 7104012 |
| LOGICOM | FAX 4 / 5 / 6 | 220 | 100 | 7104003 |
| MITA | TC 70 | 220 | 200 | 7104002 |
| MITA | TC 120 | 220 | 200 | 7104002 |
| MITA | TC 210 | 220 | 200 | 7104002 |
| MITA | TC 250 | 220 | 200 | 7104002 |
| MURATEC | M 3500 | 220 | 100 | 7104003 |
| MURATEC | M 3800 | 220 | 100 | 7104003 |
| OKI | 660 | 216 | 52 | 7104017 |
| OKI | 250 | 216 | 52 | 7104017 |
| OKI | 610 | 216 | 52 | 7104017 |
| PANASONIC | KX - F1000 | 220 | 200 | 7104002 |
| PANASONIC | KX - F1006 | 220 | 200 | 7104002 |
| PANASONIC | KX - F1020 | 220 | 200 | 7104002 |
| PANASONIC | KX - F1050 | 220 | 200 | 7104002 |
| PANASONIC | KX - F1070 | 220 | 200 | 7104002 |
| PANASONIC | KX - F1100 | 220 | 200 | 7104002 |
| PANASONIC | KX - F1150 | 220 | 200 | 7104002 |
| PANASONIC | KX - F1200 | 220 | 200 | 7104002 |
| PANASONIC | KX - F929 | 220 | 200 | 7104002 |
| PANASONIC | KX - FA 132X | 220 | 200 | 7104002 |
| PANASONIC | KX - FA 133X | 220 | 200 | 7104002 |
| PANASONIC | KX - FA 134 | 220 | 200 | 7104002 |
| PANASONIC | KX - F1810 / F1810JT | 220 | 100 | 7104003 |
| PANASONIC | KX - F1820 / F1820JT | 220 | 100 | 7104003 |
| PANASONIC | KX - F1830 | 220 | 100 | 7104003 |
| PANASONIC | KX - FA52 / KX | 215 | 30 | 7104033 |
| PANASONIC | KX - FA 135X | 220 | 100 | 7104003 |
| PANASONIC | KX - FA 136X | 220 | 100 | 7104003 |
| PANASONIC | KX - FC 241 | 220 | 30 | 7104032 |
| PANASONIC | KX - FC 243 | 220 | 30 | 7104032 |
| PANASONIC | KX - FC 245 | 220 | 30 | 7104032 |
| PANASONIC | KX - FC 248 | 220 | 30 | 7104032 |
| PANASONIC | KX - FP 141 | 220 | 30 | 7104032 |
| PANASONIC | KX - FP 143 | 220 | 30 | 7104032 |
| PANASONIC | KX - FP 145 | 220 | 30 | 7104032 |
| PANASONIC | KX - FP 148 | 220 | 30 | 7104032 |
| PANASONIC | KX - FP 205 | 215 | 30 | 7104033 |
| PANASONIC | KX - FP 205 JT | 215 | 30 | 7104033 |
| PANASONIC | KX - FP 215 JT | 215 | 30 | 7104033 |
| PANASONIC | KX - FP 255 | 215 | 30 | 7104033 |
| PANASONIC | KX - FM 220 | 220 | 100 | 7104003 |
| PANASONIC | KX - FM 300 / 330 / 320 | 220 | 100 | 7104003 |

| | | | | |
|-----------|---------------------------|-----|-----|---------|
| PANASONIC | KX - FMC 230 | 220 | 100 | 7104003 |
| PANASONIC | KX - PF 195 | 220 | 100 | 7104003 |
| PANASONIC | KX - PF 200 | 220 | 100 | 7104003 |
| PANASONIC | KX - PF 300G / JT | 220 | 100 | 7104003 |
| PANASONIC | KX - PF 320G / JT | 220 | 100 | 7104003 |
| PANASONIC | KX - FP 81 | 220 | 50 | 7104020 |
| PANASONIC | KX - FP 85 | 220 | 50 | 7104020 |
| PANASONIC | KX - FP 151 | 220 | 50 | 7104020 |
| PANASONIC | KX - FP 155 | 220 | 50 | 7104020 |
| PANASONIC | KX - FP 181 / 55X | 220 | 50 | 7104020 |
| PANASONIC | KX - FP 185 | 220 | 50 | 7104020 |
| PANASONIC | KX - FP 189 | 220 | 50 | 7104020 |
| PHILIPS | MAGIC 1 | 212 | 80 | 7104012 |
| PHILIPS | MAGIC PRIMO PPF 211 | 212 | 80 | 7104012 |
| PHILIPS | MAGIC VOX COMBI PPF 281 | 212 | 80 | 7104012 |
| PHILIPS | MAGIC VOX 1 | 212 | 80 | 7104012 |
| PHILIPS | PFA 301 | 212 | 80 | 7104012 |
| PHILIPS | PPF30 | 212 | 80 | 7104012 |
| PHILIPS | PPF35 | 212 | 80 | 7104012 |
| PHILIPS | PPF451 CON CHIP | 212 | 80 | 7104024 |
| PHILIPS | PFA 321 | 212 | 80 | 7104021 |
| PHILIPS | MAGIC 2 PRIMO PPF 441 | 216 | 80 | 7104021 |
| PHILIPS | MAGIC 2 MEMO PPF 456 | 216 | 80 | 7104021 |
| PHILIPS | MAGIC 2 VOX PPF 476 | 216 | 80 | 7104021 |
| PHILIPS | MAGIC 2 DECT PPF 486 | 216 | 80 | 7104021 |
| PHILIPS | MAGIC 3 CON CHIP | 212 | 43 | 7104030 |
| PHILIPS | PPF 531 CON CHIP | 212 | 43 | 7104030 |
| PHILIPS | PPF 532 CON CHIP | 212 | 43 | 7104030 |
| PHILIPS | PPF 571 CON CHIP | 212 | 43 | 7104030 |
| PHILIPS | PPF 575 CON CHIP | 212 | 43 | 7104030 |
| PHILIPS | PPF 581 CON CHIP | 212 | 43 | 7104030 |
| PHILIPS | PPF 585 CON CHIP | 212 | 43 | 7104030 |
| PHILIPS | PPF 591 CON CHIP | 212 | 43 | 7104030 |
| PHILIPS | PPF 595 CON CHIP | 212 | 43 | 7104030 |
| REGMA | TC 35 T | 212 | 80 | 7104012 |
| RICOH | 570 CON DECODIFICATORE | 212 | 80 | 7104012 |
| RICOH | 580 CON DECODIFICATORE | 212 | 80 | 7104012 |
| SAGEM | PHONEFAX 300 PAPIRO | 212 | 80 | 7104012 |
| SAGEM | PHONEFAX 310 | 212 | 80 | 7104012 |
| SAGEM | PHONEFAX 330 | 212 | 80 | 7104012 |
| SAGEM | PHONEFAX 350 | 212 | 80 | 7104012 |
| SAGEM | PHONEFAX 360 | 212 | 80 | 7104012 |
| SAGEM | PHONEFAX 365 PEGASO | 212 | 80 | 7104012 |
| SAGEM | PHONEFAX TTR 812 PEGASO | 212 | 80 | 7104012 |
| SAGEM | PHONEFAX TTR 815 CON CHIP | 212 | 80 | 7104024 |
| SAGEM | PHONEFAX TTR 900 CON CHIP | 212 | 45 | 7104029 |
| SHARP | FO 16 CR | 220 | 150 | 7104010 |
| SHARP | FO 1450 / 1450F | 220 | 150 | 7104010 |
| SHARP | F 1500 M | 220 | 150 | 7104010 |
| SHARP | FO 15 CR | 220 | 150 | 7104010 |
| SHARP | FO 730 | 220 | 30 | 7104011 |
| SHARP | FO - 1460 | 220 | 150 | 7104010 |
| SHARP | FO - 1650 / 1660M | 220 | 150 | 7104010 |
| SHARP | FO - 1850 / 1850F | 220 | 150 | 7104010 |
| SHARP | FO A560 | 220 | 50 | 7104031 |
| SHARP | FO A650 | 220 | 50 | 7104031 |
| SHARP | FO A660 | 220 | 50 | 7104031 |
| SHARP | FO B1600 | 220 | 50 | 7104031 |
| SHARP | FO D60 | 220 | 50 | 7104031 |

| | | | | |
|---------|------------------------------|-----|-----|---------|
| SHARP | FO P510 | 220 | 50 | 7104031 |
| SHARP | FO P600/610 | 220 | 50 | 7104031 |
| SHARP | UX - 15 CR | 220 | 150 | 7104010 |
| SHARP | UX - 1000 | 220 | 150 | 7104010 |
| SHARP | UX - 1100 | 220 | 150 | 7104010 |
| SHARP | UX - 1300 | 220 | 150 | 7104010 |
| SHARP | UX - 1400 | 220 | 150 | 7104010 |
| SHARP | UX - 1500 / 1500M | 220 | 150 | 7104010 |
| SHARP | UX - 500 | 220 | 150 | 7104010 |
| SHARP | UX - 510 | 220 | 150 | 7104010 |
| SHARP | UX - 510 IT | 220 | 150 | 7104010 |
| SHARP | UX - 600 M | 220 | 150 | 7104010 |
| SHARP | UX 310 | 220 | 30 | 7104011 |
| SHARP | UX 370 | 220 | 30 | 7104011 |
| SHARP | UX 385 | 220 | 30 | 7104011 |
| SHARP | UX 470 | 220 | 30 | 7104011 |
| SHARP | UX A-470 | 220 | 50 | 7104023 |
| SHARP | UX 485 | 220 | 30 | 7104011 |
| SHARP | NX 530 | 220 | 30 | 7104011 |
| SHARP | FO 780 | 220 | 30 | 7104011 |
| SHARP | FO 880 | 220 | 30 | 7104011 |
| SHARP | UX 470 | 220 | 30 | 7104011 |
| SHARP | UX - 600 IT | 220 | 30 | 7104011 |
| SHARP | UX - 2700 | 220 | 30 | 7104011 |
| SHARP | UX - A450 / UX 6CR | 220 | 50 | 7104023 |
| SHARP | UX A460 | 220 | 50 | 7104031 |
| SHARP | UX D50 | 220 | 50 | 7104031 |
| SHARP | UX P110 | 220 | 50 | 7104031 |
| SHARP | UX P400 | 220 | 50 | 7104031 |
| SHARP | UX P410 | 220 | 50 | 7104031 |
| SHARP | UX P420 | 220 | 50 | 7104031 |
| SHARP | UX P610 | 220 | 50 | 7104031 |
| SHARP | UX S10 | 220 | 50 | 7104031 |
| SHARP | NX 530 | 220 | 30 | 7104011 |
| SHARP | NX 670 | 220 | 30 | 7104011 |
| SHARP | NX A550 | 220 | 50 | 7104031 |
| SHARP | NX A560 | 220 | 50 | 7104031 |
| SHARP | NX D60 | 220 | 50 | 7104031 |
| SHARP | NX P500 | 220 | 50 | 7104031 |
| SHARP | NX P510 | 220 | 50 | 7104031 |
| SHARP | NX P 500 | 220 | 50 | 7104031 |
| SHARP | NX - A550 | 220 | 50 | 7104031 |
| SHARP | UX 9CR | 220 | 50 | 7104031 |
| SIEMENS | 870 | 212 | 80 | 7104012 |
| SIEMENS | 880 | 212 | 80 | 7104012 |
| SIEMENS | CX 301 | 212 | 80 | 7104012 |
| SIEMENS | CX 401 CON CHIP | 212 | 80 | 7104024 |
| SIEMENS | CX 450 CARD 815 CON CHIP | 212 | 80 | 7104024 |
| SIEMENS | TELEFAX 870 | 212 | 80 | 7104012 |
| SIEMENS | TELEFAX 890 | 212 | 80 | 7104012 |
| SIEMENS | 208 / 309 CON CHIP | 212 | 80 | 7104024 |
| TELECOM | PAPIRO (SENZA CHIP) | 212 | 80 | 7104012 |
| TELECOM | PAPIRO PLUS (SENZA CHIP) | 212 | 80 | 7104012 |
| TELECOM | NP 70 / NP 80 | 212 | 80 | 7104012 |
| TELECOM | PAPIRO TAM INTERNET CON CHIP | 212 | 80 | 7104024 |
| TELECOM | PAPIRO TAM NEW CON CHIP | 212 | 80 | 7104024 |
| TELECOM | SFERA CON CHIP | 212 | 80 | 7104028 |
| TELSTRA | 2500 | 212 | 80 | 7104012 |
| TELSTRA | 3500 | 212 | 80 | 7104012 |

| | | | | |
|-------|----------|-----|-----|---------|
| U-TAX | 2010 | 216 | 136 | 7104008 |
| U-TAX | 2021 | 216 | 136 | 7104008 |
| U-TAX | 2031 | 216 | 135 | 7104008 |
| U-TAX | F 310 | 216 | 136 | 7104008 |
| XEROX | XF 27 | 212 | 80 | 7104012 |
| XEROX | XS 27 | 212 | 80 | 7104012 |
| XEROX | FAX 7020 | 220 | 200 | 7104018 |
| XEROX | FAX 7021 | 220 | 200 | 7104018 |
| XEROX | FAX 7024 | 220 | 200 | 7104019 |
| XEROX | FAX 7033 | 220 | 200 | 7104022 |

